




CQ1 : Horizontal 80° x Vertical 40°  
 CQ2 : Horizontal 50° x Vertical 40°  
 UPQ-1P : Horizontal 80° x Vertical 50°



FRONT FILL SPEAKER  
 FF1~FF4 : 가변난간대 내부 고정 설치 되어 있음



AUDIO SYSTEM EQUIPMENT

SYMBOL	DESCRIPTIONS	MODEL	COMPANY	QTY
MSL~MSR	MAIN L/R SPEAKER	CQ-1 / CQ-2	MEYER SOUND	8EA
CS1~CS2	MAIN CENTER SPEAKER	UPQ-1P	MEYER SOUND	2EA
SW1~SW2	SUBWOOFER SPEAKER	700HP	MEYER SOUND	2EA
DFS1~DFS2	DOWN FILL SPEAKER	UPA-1P	MEYER SOUND	2EA
US1~US3	UNDER BALCONY SPEAKER	UPA-XP	MEYER SOUND	3EA
FF1~FF4	FRONT FILL SPEAKER	UPA-XP	MEYER SOUND	4EA/6EA
SR1~SR24	SURROUND SPEAKER	8340A	JBL	24EA